

INSTALLING TR6 CAM BEARINGS

- 1) Bore block to 1.9680" – 1.9685" diameter.
- 2) Chamfer edges of holes slightly.
- 3) Press bearings in squarely with oil holes aligned