

## Installation Instructions

- 1) Remove the original threaded brass or brass capped snap-in plastic plug from the bottom of the float bowl.
- 2) Clean the hole and smooth with fine emery cloth if needed for a good seal.
- 3) Remove the four screws and carefully lift off damper cover, spring and piston.
- 4) Drive the original jet downward and out of the carb body with an appropriate punch. Take great care to avoid damaging the carb body.
- 5) Install the adjustable jet as shown in the photo. Note that the small O-ring on the adjuster screw is not shown in the photo but must be present.
- 6) Adjust the jet to approx. .100" below the carb body as a starting point.

